



AEG
Electrolux CCA60S

-
- Quick heating ribbon elements
 - 9-stage power level
 - Chrome control knobs
 - 4 Residual heat indicators
 - Only 2" deep
 - Easily installed over an oven or drawer